

# LED and Beeper Indicator Tables



## A. Scanner Indicator

Status	Scanner Indicators	
	LED	Beeper
Power On	Green Light and Buzzer Simultaneously	2 loops of 3 long beeps
Battery No Power	Red Blink 3 times	3 short beeps
Battery Low Power Alarm	Red Blink 1 time	Long beep per 20 seconds
Battery Very Low Power Alarm	Red Blink 4 times	4 short beeps per 10 seconds
Memory Full	Red Blink 2 times	2 long beeps
Transmitted Success	Green Blink 1 time	1 long beep
Transmitted Fail	Red Blink 2 times	2 short beeps
Configure Setup	Green Light and Buzzer Simultaneously	3 short beeps
BT Connecting Build	Blue Blink 2 times per second	N/A
BT Connecting Success	Blue light 2 seconds	3 up-Tone
BT Connected	Blue Blink per Second	N/A
BT Disconnect	Blue Light 2 seconds	3 down-Tone
Charging	Red Light Continue	N/A
Full Charge	Green Light Continue	N/A
Enter Sleep	N/A	Down-Tone



## B. Cradle Indicator

Status	Cradle Indicators	
	LED	Beeper
Power On*	Red Light Continue	N/A
Transmitted Success	Green Blink 1 Time	N/A
BT Connected	Blue Blink Continue	N/A
BT Disconnect	Blue Blink 2 Times per Second	N/A

\*Only applicable to model number MHT349.