


FINO & LUSO WALL & DESK MOUNT



Before you start: Determine if you want to use the tablet in portrait or landscape position. In portrait position; make sure the key lock is on top. Or use additional turn disc.

Note: Fitting the flat side of the tube **[C]** to the base plate **[D]** results in a straight tube (regular), mounting the diagonal side to the base plate results in an upward tube (variation).

1 Fit plate **[D]** on flat side tube **[C]**; Mount **[A]** M6 x 16 on the countersunk side.

Optional : Guide power cable through hole in tube to bottom.

2 Mount the base to wall or desk. (Plugs and screws not included)

Optional: Place additional cover ring over the tube to cover base plate.

3 Fit casing **[B]** on the diagonal side tube **[C]** ; Use **[A]** M6 x 16

Optional: Guide power cable through hole in casing.

4 Position tablet into casing by sliding it in from the top or side.

Optional: If the casing doesn't fit tight around the tablet, place the optional rubbers as shown on the picture **[E]**. (See manual: Fixing the rubbers)

5 Position closing part into the casing and lock with built in key lock.

